

Assembling CTFDINPC-2



Place the CTFDINPC-2 as shown below.





Remove the 4 screws.







CARTFT.COM Shep for mobile PC- and GPS-Solutions





Remove the upper case. (by pulling it towards you)



CARTFT.COM Shep for mobile PC- end GPS-Solutions





Take your 2.5" HDD/SSD and install it.

















You can connect the HDD/SSD with the cable shown below.







Close the lid again and fasten the screws.













© CarTFT.com 2009





Now connect the cables.

















For beeing able to start CTFDINPC-2 you at least need to connect these 3 wires :





Black = Ground (-) Yelllow = Plus (+) Red = Ignition plus (ACC +)